

Direction Départementale des Territoires du Bas-Rhin

PLAN DE PRÉVENTION DU RISQUE D'INONDATION

Bassin versant de l'Ehn, de l'Andlau et de la Scheer

PROJET DE

PLAN DE ZONAGE RÉGLEMENTAIRE

Commune de Ottrott - Centre

Légende

Côte des Plus Hautes Eaux NGF IGN 69 (en m)

Zones d'interdiction

Zone rouge foncé (aléa fort à très fort en zone non urbanisée)

Zone rouge clair (aléa faible à modéré en zone non urbanisée)

Zone orange (aléa fort en zone urbanisée)

Zones d'autorisation sous conditions

Zone bleu clair (aléa faible à modéré en zone urbanisée)

Zone bleu très clair (aléa faible à modéré en centre urbain)

Zone bleu foncé (aléa fort en centre urbain)

Éléments de repérage

Routes principales

Autoroutes

Limite communale

Bâtiment

Voies ferrées

Tronçons Cours d'Eau

Parcelles cadastrales

00.10.2

km

1:5 000

Direction Départementale des Territoires du Bas-Rhin

www.bas-rhin.gouv.fr

N

A detailed flood risk map of the Ottrott - Centre area. The map displays various risk zones: 'Zone rouge foncé' (dark red) for high flood risk in non-urbanized areas, 'Zone rouge clair' (light red) for moderate risk in non-urbanized areas, 'Zone orange' (orange) for high risk in urbanized areas, 'Zone bleu clair' (light blue) for moderate risk in urbanized areas, 'Zone bleu très clair' (very light blue) for moderate risk in urban centers, and 'Zone bleu foncé' (dark blue) for high risk in urban centers. Infrastructure elements include main roads (thin grey lines), highways (thick red lines), communal boundaries (dashed grey lines), buildings (black outlines), railways (dotted grey lines), watercourse segments (blue lines), and cadastral parcels (thin grey outlines). A scale bar indicates 0 to 0.2 km at 1:5,000. A north arrow is located in the bottom right corner. The map is titled 'PLAN DE PRÉVENTION DU RISQUE D'INONDATION' and 'Bassin versant de l'Ehn, de l'Andlau et de la Scheer'. It is a 'PROJET DE PLAN DE ZONAGE RÉGLEMENTAIRE' for the 'Commune de Ottrott - Centre'. The legend is located in the top left corner, and the scale and north arrow are in the bottom left corner.